



ASSEMBLY INSTRUCTIONS:

ASSEMBLE THE BASE
 UPSIDE DOWN FOR
 BEST POSITIONING.

THREADED TIE ROD (1) GOES
 THROUGH TOP OF THE SPIDER (2)
 SLIDE TUBE (3) OVER ROD UNTIL
 IT MEETS THE SPIDER. PLACE
 BASE BOTTOM DOWN OVER ROD
 TO MEET WITH THE TUBE. LOCK
 IN PLACE WITH THE KEP NUT (5)

ASSEMBLED PRODUCT PHOTO

