


Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly required. Online Parts Request: parts.request@hillsdalefurniture.com - Customer Service Phone Number: 502-562-0000

HARDWARE LIST

- A (16) Allen Bolts 1/4"
- B (16) Spring Washers 1/4"
- C (16) Camber Washers 1/4"
- D (4) Wood Screws
- E (1) Allen Wrench

PARTS LIST

- F (1) Seat Base
- G (4) Legs
- H (1) Support Ring
- J (1) Seat Cushion



***** ASSEMBLY *****

STEP 1

Begin the assembly by first attaching each Leg (G) to each opening on the Seat Base (F) by sliding into place. Secure in place using 2 Allen Bolts (A), 2 Spring Washers (B) & 2 Camber Washers (C) per each leg. Do not fully tighten bolts.

STEP 2

Attach the Support Ring (H) to each Leg (G) by resting the ring on each metal holder, and securing in place using 2 Allen Bolts (A), 2 Spring Washers (B) & 2 Camber Washers (C) per each leg. Tighten all bolts from Steps 1 & 2 using the Allen Wrench (E).

STEP 3

Finally, attach the Seat Cushion (J) to the Seat Base (F) and secure in place at each metal tab using 1 Wood Screw (D) per each tab. Tighten all screws only using a phillips head screwdriver (not included). The assembly is now complete.

